ANSI N42.55 test results for Default System system using Example X-ray source source

Example Data
PDF generated 2020-08-24 at 16:58
Analyzed using Glover ANSI N42.55 Python code (version 0.13)

Main test object images:

example_images/N4255_1.tif example_images/N4255_2.tif example_images/N4255_3.tif example_images/N4255_4.tif

Image extent image:

example_images/N4255_5.tif

Noise images:

example_images/N4255_1_blank.tif example_images/N4255_2_blank.tif example_images/N4255_3_blank.tif example_images/N4255_4_blank.tif example_images/N4255_5_blank.tif


ANSI N42.55 test results

Metric name	Metric Value	Min. Performance Req.
Test 1: Penetration	None mm*	≥ 6 mm
Test 2: Organic Material Detection	-1.1*	≥ 2.0
Test 3: Spatial Resolution		
MTF20x	1.45 lp/mm ± 0.05 lp/mm†	≥ 0.5 lp/mm
Test 4: Dynamic Range	254.6 ± 21.9†	≥ 150
Test 5: Noise		
NEQx at 1 lp/mm	295,089 ± 15,693†	≥ 22,500
NEQy at 1 lp/mm	311,106 ± 11,337†	≥ 22,500
Test 6: Flatness of field	0.991 ± 0.00†	≥ 0.5
Test 7: Image extent	1 mm*	≤ 10 mm
Test 8: Image area	2876 by 2350 pixels	≥ 1000 by 1000 pixels
Test 9: Aspect Ratio	0.021 ± 0.001†	≤ 0.05

[†] These values represent the mean and one-sigma uncertainty in the quantity of interest. In some cases, the metric mean must be two sigma away from the min performance requirement in order to pass. See IEEE/ANSI N42.55 for full details.

[♣] These tests do not have uncertainty values defined in the standard.

Cropped and Rotated Images








Image 1 is shown in its original orientation. The other three images have been rotated to be in the same orientation as image 1. Images 2, 3 and 4 were originally in an orientation that was rotated by 90, 180 and 270 degrees clockwise compared with image 1. This convention is continued throughout the document.

Colored boxes have been drawn around important regions of the image.
The blue ROI should surround the Pb foil test piece, leaving some room on all sides of it.
The red ROI should be placed on the POM test piece, between the two bolts.
The orange ROI should span the middle portion of the steel step wedge, running the entire vertical length of the image.


Test 1: Steel penetration (None mm) boundary images shown below




Test 2: Organic Detection (-1.1)





Test 3: Spatial Resolution MTF20x = 1.45 MTF20y = 1.44







Test 3: Spatial Resolution MTF20x = 1.45 MTF20y = 1.44







Test 3: Spatial Resolution MTF20x = 1.45 MTF20y = 1.44






Test 3: Spatial Resolution MTF20x = 1.45 MTF20y = 1.44





Test 4: Dynamic Range (254.6)




$$NEQ = \frac{S_{out}^2 MTF^2}{NPS}$$

 NPS_{x} (at 1 lp/mm) = 360.4

 MTF_{x} (at 1 lp/mm) = 0.396

 S_{out} (at 1 lp/mm) = 26,034

 NEQ_x (at 1 lp/mm) = 295,089 ± 15,693



Test 5: Noise (NEQ_y at 1 lp/mm: 311,106)


$$NEQ = \frac{S_{out}^2 MTF^2}{NPS}$$

 NPS_y (at 1 lp/mm) = 346.6


 MTF_y (at 1 lp/mm) = 0.398


 S_{out} (at 1 lp/mm) = 26,034

 NEQ_y (at 1 lp/mm) = 311,106 ± 11,337



Test 6: Flatness of Field (0.99)





Test 7: Image Extent (1.0 mm)

distance 1 mm dynamic range 208.9 distance 5 mm dynamic range 204.2 distance 10 mm dynamic range 206.7

